
At the end of the day/shift, or if the printheads are not being used for several hours, use the machine capping station to protect the printheads from dirt, debris and light.



After longer periods of shutdown, follow the manufacturer's procedures for restart and carry out the cleaning procedures in Step 2.



Do NOT touch the sensitive parts of the printhead. Always protect the printhead from static damage and wear gloves at ALL times.



DAILY
PRINTHEAD
MAINTENANCE

Xaar 1003

*Also for the Xaar 1001 and 1002.

Xaar plc 316 Science Park Cambridge CB4 0XR United Kingdom +44 (0)1223 423663 info@xaar.com www.xaar.com





DAILY PRINTHEAD MAINTENANCE

The printhead is a precision high-quality product.


Protect and care for it to ensure optimal performance.

Always refer to the machine manufacturer's maintenance procedures.





At the start of the day/shift carry out a visual inspection of the printhead for contamination or debris.



Detailed below is the procedure for cleaning contamination from the printhead. Always use the correct method for wiping the nozzle plate.

